

# SpringCard™

## Smart-card reader module for Visor



**Pro-Active' SpringCard** is a smart-card reader module for the **HandSpring Visor** PDA family.

**SpringCard** is the perfect framework to develop any **PalmOS** software that embed smart-card technology.



### SpringCard Features and benefits :

- ✓ ISO smartcard reader & SIM/SAM smartcard reader.
- ✓ **GemCore** Chipset, giving access to microprocessor cards **ISO7816-1,2,3,4** (T=0, T=1) and to every sort of **memory cards** (except SIM/SAM), in 3 or 5V.
- ✓ Usable with any **Visor** through its **SpringBoard** expansion slot.
- ✓ Super-slim format.
- ✓ Directly powered by the **Visor**.
- ✓ **Embedded 2Mb flash memory**, suitable for application delivery and as a backup area for every **Visor** data file.

# Pro Active®



### A few applications...

- ✓ Hand-terminal for any smart-card system
- ✓ Virtual wallet
- ✓ Access control tags programming
- ✓ Data exchange through memory cards

## SpringCard Development Kit

This kit includes :

- ✓ One **SpringCard** module.
- ✓ One **SpringCard Starter Kit**.
- ✓ One Visor PDA.
- ✓ Metrowerks **CodeWarrior for PalmOS** development environment.
- ✓ The **GemCore-access-API** (**CodeWarrior** library).
- ✓ A demo software (APDU Exchange), with its C-source-code (**CodeWarrior** environment).
- ✓ The developer's guide.
- ✓ 3 months technical support by e-mail.



**Pro-Active** can also design and develop your own **SpringCard** based application !

**PRO ACTIVE**  
Parc Gutenberg  
13, voie La Cardon  
91120 PALAISEAU  
FRANCE

[www.pro-active.fr](http://www.pro-active.fr)

Tel : +33 (0) 1 64 53 20 15  
Fax : +33 (0) 1 64 53 20 18  
E-mail : [info@pro-active.fr](mailto:info@pro-active.fr)

Distributed by :