

PROX'N'ROLL RFID SCANNER

Quick Start Guide

Thank you for choosing SpringCard !

Prox'N'Roll RFID scanner is a versatile 13.56 MHz RFID scanner. Its USB interface emulates a standard keyboard : no driver installation, no software required!

Prox'N'Roll RFID scanner is highly configurable to read serial number or data from any RFID tag or contactless smartcard.

This document will help you to connect this product.

USING THE PROX'N'ROLL

The SpringCard ProxRunner is seen as a keyboard. Thus you must put your cursor where you want the data to be written.

Next put a card on the reader.

CONFIGURING THE PROX'N'ROLL

Let the Master card on the reader **until the leds blink and the buzzer emits a long pulse.**

For more information, go to SpringCard's solutions page at www.springcard.com/solutions/rfidscanner.html

AZERTY KEYBOARD

Master Card for Prox'N'Roll RFID Scanner

Put this card on your reader to configure it in **AZERTY** keyboard to read IDs of :

ISO/IEC 14443 A & B
ISO/IEC 15693
NXP ICODE 1
ST SR Family
ASK CTS256B & CTS512B
Calypso (Innovatron)

QWERTY KEYBOARD

Master Card for Prox'N'Roll RFID Scanner

Put this card on your reader to configure it in **QWERTY** keyboard to read IDs of :

ISO/IEC 14443 A & B
ISO/IEC 15693
NXP ICODE 1
ST SR Family
ASK CTS256B & CTS512B
Calypso (Innovatron)

Headquarters, Europa

SpringCard
13 Voie la Cardon
Parc Gutenberg
91120 Palaiseau
FRANCE

Phone : +33 (0) 1 64 53 20 10
Fax : +33 (0) 1 64 53 20 18

Americas

SpringCard
694 Fifth Avenue
Suite 235
San Diego, CA 92101
USA

Phone : +1 (619) 544 1450
Fax : +1 (619) 573 6867

www.springcard.com

EDITOR'S INFORMATION
PRO ACTIVE SAS company with a capital of 227 000 €
RCS EVRY B 429 665 482
Parc Gutenberg, 13 voie La Cardon
91120 PALAISEAU - FRANCE